# TODAY SLEEPER

DISASSEMBLY AND ASSEMBLY INSTRUCTIONS

AMERICAN LEATHER

# TODAY SLEEPER

- SHEET 3-4: HOW TO DISASSEMBLE
- SHEET 5: EXPLODED VIEW.
- SHEET 6-7: MECHANISM REMOVAL.
- SHEET 8-9: HOW TO REASSEMBLE

AMERICAN LEATHER

# DISASSEMBLY INSTRUCTIONS:

## STEP 1:

OPEN FRONT BED SECTIONS.

## STEP 2:

REMOVE 5/16" BOLT USING A 1/2" DRIVER.

TOP VIEW
LOOKING DOWN

DETAIL A

SCALE 1:2

## STEP 3:

REMOVE 5/16" BOLT
USING A 1/2" DRIVER.
REPEAT ON OPPOSITE
SIDE.

SIDE VIEW

AMERICAN LEATHER

# DISASSEMBLY INSTRUCTIONS (CONTINUED):

## STEP 4:

FLIP FRONT BED SECTION BACK
AS SHOWN.

## STEP 5:

REMOVE 5/16" BOLT USING A
1/2" DRIVER.
REPEAT ON OPPOSITE SIDE.

## STEP 6:

CLOSE BED SECTIONS AND PUT SUPPLIED SEAT STRAPS ON
BEFORE MOVING.

## STEP 7:

ROTATE BED SECTIONS FORWARD.

## STEP 8:

REMOVE 5/16" BOLTS USING A
1/2" DRIVER.
REPEAT ON OPPOSITE SIDE.

## FULLY DISASSEMBLED SECTIONS.

AMERICAN LEATHER

# TODAY SLEEPER EXPLODED VIEW:

AMERICAN LEATHER

# HOW TO REMOVE MECHANISM:

## STEP 1:
OPEN FRONT BED SECTIONS.

## STEP 2:
TILT FRONT BED SECTION BACKWARDS.
ONLY ONE AT A TIME.

## STEP 3:
HAVE SOMEONE STAND BEHIND SOFA AND
HOLD BED SECTION UP AND IN PLACE.

## STEP 4:
REMOVE THE 4 BOLTS AS SHOWN BELOW.

SECTION A-A

SCALE 1:20

REMOVE TWO BOLTS AS SHOWN.
BOTH SIDES OF SEAT.

DETAIL B

SCALE 1:2

AMERICAN LEATHER

# HOW TO REMOVE MECHANISM:

## STEP 5:

REMOVE  BOLTS AS SHOWN BELOW.
- BOLT "A" REMOVES MECHANISM.
- BOLT "B" REMOVES HINGES.

!!! TAKE NOTE OF BRACKET OREINTATION !!!
MOUNTING IN THIS OREINTATION IS CRITICAL!!!

SIDE VIEW OF MECHANISM INSTALLED.

AMERICAN LEATHER

# REASSEMBLY INSTRUCTIONS:

- FOLLOW STEPS IN ORDER.

STEP 1:
ROTATE BED SECTIONS FORWARD.

STEP 2:
INSTALL 5/16" BOLTS USING A 1/2" DRIVER.
REPEAT FOR OPPOSITE SIDE.

STEP 3:
MOVE FRONT BED SECTION ASSEMBLY
INTO PLACE.

STEP 4:
CLOSE BED SECTIONS.

AMERICAN LEATHER

## STEP 5:

INSTALL 5/16 BOLT USING 1/2" DRIVER, BOTH SIDES.

## STEP 6:

INSTALL 5/16" BOLT USING A 1/2" DRIVER.

DETAIL A

SCALE 1:2

TOP VIEW
LOOKING DOWN

## STEP 7:

FLIP FRONT BED SECTION BACK AS SHOWN.

## STEP 8:

INSTALL 5/16 BOLT USING 1/2" DRIVER, BOTH SIDES.

## STEP 9:

CLOSE BED SECTIONS.
ASSEMBLY COMPLETE.

AMERICAN LEATHER